

# IMPORTANT TIPS FOR THE EMINENCE PORTABLE UPRIGHT BASS

## BRIDGE PLACEMENT

The **most important** thing to remember when setting up your Eminence Bass is to make sure the bridge is **not** tipping forward. Push the top of the bridge back towards the endpin with your thumb, centered at the top of the bridge. When viewed from the side, the bridge should look like it's tipping backwards toward the endpin.

## REPLACING STRINGS - TUNER PEG TIP

When replacing strings, make sure to shorten the length so that when wound on the tuning post they do not bind between the bottom of the tuning post and the peg box. In other words, if a string touches the wood below the tuning post and starts to bind, the gears of the tuner may become stripped.

## ENDPIN SCREWS

When tightening, tighten the back endpin screw first, then the side one; when loosening, loosen the side screw first, then the back one.

Call Gary toll free at **800-741-3045** for ANY question you may have about your Eminence Bass.

G. EDWARD LUTHERIE INC.

1620 Central Avenue Northeast Minneapolis, MN 55413 USA  
800.741.3045 • 612.781.5799 • [www.gelbass.com](http://www.gelbass.com) • [gelbass@aol.com](mailto:gelbass@aol.com)